

**Air Conditioning Support Bracket  
for use small block MuscleMaxx  
headers by Dynatech**

**Part # 794-03006**

**This bracket is for use with the OEM Delco Air Conditioning Compressor.**

With the header installed remove the two bolts between the #1 and the #3 cylinder. Replace them with 1.5 inch long grade five bolts. The header may have to be loosened to provide clearance to start the bolt closest the # 1 cylinder. Tighten the bolts just enough so that the bracket can be moved for adjustment. Measure the distance between the back of the front A/C bracket and the back side of the rear support bracket. Adjust the rear support bracket so that the measurement is 7 7/8" between the front and rear bracket. (See the pictures below.) Once you are satisfied with the measurement, completely tighten the bolts holding the bracket and any other bolts that were loosened during installation. Install the A/C compressor, tighten all bolts, and check the belt alignment.

