



PRO Rebound Adjustable Shocks 6-11

Rebound Adjuster Instructions

Features & Benefits

- 6 to 11 Rebound adjustment range.
- Positive detent locating mechanism for fine tuned adjustability.
- +/- indicator
 - o Turn the adjuster screw in the “+” direction to increase rebound resistance.
 - o Turn the adjuster screw in the “-” direction to decrease rebound resistance.
- Click adjuster enables the rebound to be reset the same every time.
- Re-buildable housing improves life of adjuster with yearly maintenance.

Setting your adjuster

- Ensure your adjuster is set at the full soft position (all the way toward the “-” setting).
- Count your clicks as you turn the adjuster to the “+” position.



Reference setting for Rebound

- | | |
|-------------|--|
| •6 Rebound | All the way “-” (minus) [starting point] |
| •7 Rebound | +6 clicks from full soft. |
| •8 Rebound | +8 clicks from full soft. |
| •9 Rebound | +12 clicks from full soft. |
| •10 Rebound | +14 clicks from full soft. |
| •11 Rebound | +16 clicks from full soft. |

DELIVERING CHAMPIONSHIPS
And big Trophies
FOR OVER 30 YEARS

855.682.4404

PROshocks.com

