



## **Rebound Adjuster Instructions**

#### **Features & Benefits**

- 7 to 12 Rebound adjustment range.
- Positive detent locating mechanism for fine tuned adjustability.
- +/- indicator
  - o Turn the adjuster screw in the "+" direction to <u>increase</u> rebound resistance. o Turn the adjuster screw in the "-" direction to decrease rebound resistance.
- Click adjuster enables the rebound to be reset the same every time.
- Re-buildable housing improves life of adjuster with yearly maintenance.

### Setting your adjuster

- Ensure your adjuster is set at the full soft position (all the way toward the "-" setting).
- Count your clicks as you turn the adjuster to the "+" position.

### **Reference setting for Rebound**

- •7 Rebound 4 All the way "-" (minus) [starting point]
- •8 Rebound
  •9 Rebound
  •10 Rebound
  •11 Rebound
  •11 Rebound
  •12 clicks from full soft.
  +12 clicks from full soft.
  +13 clicks from full soft.
  +14 clicks from full soft.
- •12 Rebound +16 clicks from full soft.

# DELIVERING CHAMPIONSHIPS And big FOR OVER 30 YEARS

855.682.4404

PROshocks.com







